



IN CONTACT

CONFIGURATION AND KIT LIST: K1



CONFIGURATION AND KIT LIST

K1

LARGE FORMAT LINE SOURCE

Date : 01/05/2014



⌘ K1 KIT LIST - NOMINAL FULL PACKAGE WITH 48K1 - 24 K1-SB - 24 SB2

K STANDARD

| KI SYSTEM | DESCRIPTION | 48 KI 24 K2 |
|---------------------|---|----------------|
| K1 | 3-way full-range active WST® enclosure | 48 |
| K1-PLA | Removable front dolly for K1 or K1-SB enclosure | 0 |
| K1-COV | Protective cover for K1 enclosure | 0 |
| K1-CHARIOT2 | Chariot for 4 x K1 or 4 x K1-SB (V2) | 12 |
| K1-CHARIOTCOV | Protective cover for 4 x K1/K1-SB on CHARIOT | 12 |
| DO.7 | Speaker cable: 8 x 4mm ² CA-COM 0.7m length | 24 |
| DO25 | Speaker cable: 8 x 4mm ² CA-COM 25m length | 24 |
| K1-BUMP | Structure for flying & stacking K1 and K1-SB arrays | 4 |
| K1-DELTA | Rigging accessory for rear attachment of 2 motors to K1-BUMP | 4 |
| K1-LASERMOUNT | K1 Laser mount | 4 |
| K1-BUMPFLIGHT | Modular flight case for 2 K1-BUMP | 2 |
| LA-RAK EMPTY | Touring Rack (RK9U/LA-POWER/LA-PANEL/ LA-PANELAES3/2U panels) | 10 |
| LA8 | Amplified controller 4 x 1800 W/4 Ohms. ethernet network. AES/EBU | 30 |
| LA-RAK BUMP | Structure for flying 4 x LA-RAK | 3 |
| DOM2 | 6 pair multiconductor cable AMP LINK 2m length | 10 |
| DOM45 | 6 pair multiconductor cable CROSS LINK 45m length | 5 |
| DOMF | Multipair cable adapter LINK-BREAKOUT 6 x LR3 female | 5 |
| DOMM | Multipair cable adapter LINK-BREAKOUT 6 x LR3 male | 2 |
| DOMP2 | Male/Male adapter LINK-EXTEND for AMP & CROSS LINK | 2 |
| KARA | 2-way modular WST® enclosure | 12 |
| SP.7 | Speaker cable: 4 x 4mm ² NL4 0.7m length | 8 |
| DO25 | Speaker cable: 8 x 4mm ² CA-COM 25m length | 4 |
| DOFILL-LA8 | Speaker cable extension for active 2 way enclosures CA-COM > 2 x NL-4 | 4 |
| KARA-DOWNKI | Flying bumper for rigging KARA under K1 or K1SB | 4 |
| KI-SB SYSTEM | | |
| K1-SB | K1 System subwoofer 2 x 15" | 24 |
| K1-PLA | Removable front dolly for K1 or K1-SB enclosure | 0 |
| K1-SBCOV | Protective cover for K1-SB enclosure | 0 |
| K1-CHARIOT2 | Chariot for 4 x K1 or 4 x K1-SB (V2) | 6 |
| K1-CHARIOTCOV | Protective cover for 4 x K1/K1-SB on CHARIOT | 6 |
| DO25 | Speaker cable: 8 x 4mm ² CA-COM 25m length | 8 |
| DOSUB-LA8 | Speaker cable breakout for passive enclosures CA-COM > 4 x NL-2 | 8 |
| K1-BUMP | Structure for flying & stacking K1 and K1-SB arrays | 4 |
| K1-DELTA | Rigging accessory for rear attachment of 2 motors to K1-BUMP | 4 |
| K1-BUMPFLIGHT | Modular flight case for 2 K1-BUMP | 2 |
| LA-RAK EMPTY | Touring Rack (RK9U/LA-POWER/LA-PANEL/ LA-PANELAES3/2U panels) | 2 |
| LA8 | Amplified controller 4 x 1800 W/4 Ohms. ethernet network. AES/EBU | 6 |
| LA-RAK BUMP | Structure for flying 4 x LA-RAK | 1 |
| DOM2 | 6 pair multiconductor cable AMP LINK 2m length | 2 |
| DOM45 | 6 pair multiconductor cable CROSS LINK 45m length | 1 |
| DOMF | Multipair cable adapter LINK-BREAKOUT 6 x LR3 female | 1 |
| K2 SYSTEM | | |
| K2 | 3-way full-range active WST enclosure | 24 |
| K2-CHARIOT | Chariot for 4 x K2 | 6 |
| K2-CHARIOTCOV | Protective cover for 4 x K2 on CHARIOT | 6 |
| K2-JACK | 4 x tilt adjustment screw jacks + bar for K2-CHARIOT | 6 |
| DO.7 | Speaker cable: 8 x 4mm ² CA-COM 0.7m length | 12 |
| DO25 | Speaker cable: 8 x 4mm ² CA-COM 25m length | 12 |
| K2-BUMP | Structure for flying K2 arrays (incl. 1 x Extension Sling + 1 TEQSAS Laser Adapter) | 4 |
| K2-BAR | Extension Bar for K2-BUMP | 4 |
| K1-DELTA | Rigging accessory for rear attachment of 2 motors to K1-BUMP | 4 |
| K2-LASERMOUNT | K2 Lasermount (compatible TEQSAS, SSE ProSight, Align Array) | 4 |
| K2-RAKMOUNT | 4 x mounting cradle for LA-RAK (incl. Rack Stabilizer) | 4 |
| K2-BUMPFLIGHT | Modular K1-BUMPFLIGHT flight case adapted for 2 x K2-BUMP | 2 |
| K2-LINK | Rigging accessory for rear attachment of K2 below K1 | 4 |



| | | |
|----------------------------------|--|----|
| LA-RAK EMPTY | Touring Rack (RK9U/LA-POWER/LA-PANEL/ LA-PANELAES3/2U panels) | 4 |
| LA8 | Amplified controller 4 x 1800 W/4 Ohms. ethernet network. AES/EBU | 12 |
| LA-RAK BUMP | Structure for flying 4 x LA-RAK | 4 |
| DOM2 | 6 pair multiconductor cable AMP LINK 2m length | 4 |
| DOM45 | 6 pair multiconductor cable CROSS LINK 45m length | 2 |
| DOMF | Multipair cable adapter LINK-BREAKOUT 6 x LR3 female | 2 |
| DOMM | Multipair cable adapter LINK-BREAKOUT 6 x LR3 male | 1 |
| DOMP2 | Male/Male adapter LINK-EXTEND for AMP & CROSS LINK | 1 |
| SB28 SYSTEM | | |
| SB28 | High power subwoofer: 2 x 18" | 24 |
| SB28PLA | Removable front dolly for SB28 enclosure | 24 |
| SB28COV | Protective cover for SB28 enclosure | 24 |
| DO25 | Speaker cable: 8 x 4mm ² CA-COM 25m length | 6 |
| DOSUB-LA8 | Speaker cable breakout for passive enclosures CA-COM > 4 x NL-2 | 6 |
| LA-RAK EMPTY | Touring Rack (RK9U/LA-POWER/LA-PANEL/ LA-PANELAES3/2U panels) | 2 |
| LA8 | Amplified controller 4 x 1800 W/4 Ohms. ethernet network. AES/EBU | 6 |
| DOM2 | 6 pair multiconductor cable AMP LINK 2m length | 2 |
| DOM45 | 6 pair multiconductor cable CROSS LINK 45m length | 1 |
| DOMF | Multipair cable adapter LINK-BREAKOUT 6 x LR3 female | 1 |
| DOMM | Multipair cable adapter LINK-BREAKOUT 6 x LR3 male | 1 |
| TECH TOOLCASE | | |
| TECH TOOLCASE | System technician tool case | 1 |
| TRAINING | | |
| TRA_DOM | On-site training 1 day (domestic) | 0 |
| TRA_REG | On-site training 1 day (regional) | 0 |
| TRA_INT | On-site training 2 days (international) | 1 |
| TRA_ADD | Additional on-site training day | 1 |
| TRA_VOUI | 1 day training valid for one participant | 0 |
| SOUNDVISION | | |
| SOUNDVISION | 3D simulation software free of charge | 1 |
| SOUNDVISION | 3D simulation software available at www.l-acoustics.com | 1 |
| SERVICE STARTER KIT K1 | | |
| KR HSBC33 | Kit diaphragm for 3" driver | 3 |
| KR HPBC33 | Kit HP BC33 Driver 3" - 20 ohms | 3 |
| KR HPPH62 | Kit HP PH62 Speaker 6.5" - 8 ohms | 4 |
| KR HPPH154 | HP PH154 (15" speaker - 8 ohms) | 2 |
| KR PINI63 | Kit K1 6 ball head pins | 1 |
| KR PINI83 | Kit K1 bumper 2 pins | 1 |
| SERVICE STARTER KIT K1-SB | | |
| KR HPPH154 | HP PH154 (15" speaker - 8 ohms) | 2 |
| KR PINI63 | Kit K1 6 ball head pins | 1 |
| SERVICE STARTER KIT K2 | | |
| KR HSBC34 | Diaphragm for HP BC34II (3" driver - 8 ohms) | 2 |
| KR HPBC34 | Kit HP BC34 Driver 3" - 8 ohms | 2 |
| KR HPFA61 | Kit HP FA61 Driver 6.5" - 8 ohms | 2 |
| KR HPBC125 | 12" speaker - 8 ohms | 2 |
| KR PINI63 | Kit K1 6 ball head pins | 2 |
| KR PINI394 | Kit 2 x pin 1394 | 2 |
| KR PINI542 | Kit 2 x pin 1542 | 1 |
| SERVICE STARTER KIT KARA | | |
| KR HSBC34 | Diaphragm for HP BC34II (3" driver - 8 ohms) | 1 |
| KR HPBC34 | Kit HP BC34 Driver 3" - 8 ohms | 1 |
| KR HPPH85 | Kit HP PH85 Speaker 8" - 16 ohms | 2 |
| KR PIN62I | Kit 10 pins short round head screws & rivets | 1 |
| KR PIN60I | Kit 10 pins long T-shaped head screws & rivets | 1 |
| SERVICE STARTER KIT SB28 | | |
| KR HPBM181 | Kit HP BM181 Speaker 18" | 2 |
| KR CAPLATPIN | Kit 10 pins for dolly boards | 1 |



NOMINAL PACKAGE SPLIT 1/2 1/2

