



CONTACT

CONFIGURATION AND KIT LIST: KUDO



## CONFIGURATION AND KIT LIST

### KUDO

### LARGE FORMAT LINE SOURCE

Date : 10/2013

[www.l-acoustics.com](http://www.l-acoustics.com)

13, rue Levacher Cintrat • 91462 Marcoussis Cedex • France • Ph. : +33 (0)1 69 63 69 63 • Fax: +33(0) 1 69 63 69 64 • e-mail: [info@l-acoustics.com](mailto:info@l-acoustics.com) 1/4



## CONFIGURATION AND KIT LIST: KUDO

### ☛ KUDO KIT LIST

H STD K STANDARD

KUDO SYSTEM	DESCRIPTION	12 KUDO	18 KUDO	24 KUDO
LA-RAK EMPTY	Touring Rack (RK9U/LA-POWER/LA-PANEL/ LA-PANELAES3/2U panels)	2	3	5
LA8	Amplified controller 4 x 1800 W/4 Ohms. ethernet network. AES/EBU	6	9	15
DOM2	6 pair multiconductor cable AMP LINK 2m length	2	3	5
DOM45	6 pair multiconductor cable CROSS LINK 45m length	2	2	2
DOMF	Multipair cable adapter LINK-BREAKOUT 6 x LR3 female	1	1	1
DOMM	Multipair cable adapter LINK-BREAKOUT 6 x LR3 male	1	1	1
DOMP2	Male/Male adapter LINK-EXTEND for AMP & CROSS LINK	1	1	1
KUDO	3-ways full-range active WST® enclosure (CA-COM)	12	18	24
KPLA-2	Removable front dolly on wheels	12	18	24
KUDOCOV	Protective cover for KUDO enclosure	12	18	24
DO.7	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 0.7m length	8	12	12
DO25	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length	4	6	8
KBUMP	Rigging & stacking bumper for installing KUDO vertically	2	2	2
KLIFT	Rigging bumper for installing KUDO horizontally	4	4	4
KJACKx2	2 x tilt adjustment screw jacks for KUDO bumper	2	2	2
<b>SB18/SB28 SUB SYSTEM</b>	<b>DESCRIPTION</b>			
SB18	High power compact subwoofer: 1 x 18"	8	0	0
SB18PLA	Removable front dolly on wheels for SB18/SB18m enclosure	8	0	0
SB18COV	Protective cover for SB18(m) enclosure	8	0	0
DO25	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length	2	2	3
DOSUB-LA8	Speaker cable breakout for passive enclosures CA-COM > 4 x NL-2	2	2	3
SB28	High power subwoofer: 2 x 18"	0	8	12
SB28PLA	Removable front dolly for SB28 enclosure	0	8	12
SB28COV	Protective cover for SB28 enclosure	0	8	12
DO.7	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 0.7m length	2	2	2
SP25	Speaker cable: 4 x 4mm <sup>2</sup> NL4 25m length	4	0	0
SP.7	Speaker cable: 4 x 4mm <sup>2</sup> NL4 0.7m length	4	0	0
<b>12 XT SYSTEM*</b>	<b>DESCRIPTION</b>			
12XT	2-way active/passive coaxial enclosure: 12" LF+ 3" HF diaphragm	4	4	0
ETRI2-2	Adjustable U bracket: 12XT-112P-112XT	4	4	0
SP25	Speaker cable: 4 x 4mm <sup>2</sup> NL4 25m length	4	4	0
SP10	Speaker cable: 4 x 4mm <sup>2</sup> NL4 10m length	2	2	0
SP.7	Speaker cable: 4 x 4mm <sup>2</sup> NL4 0.7m length	2	2	0
CC4FP	Speakon > Speakon adaptor	4	0	0
*Optional fill system (LA-RAK resources dependant)				
<b>TRAINING</b>	<b>DESCRIPTION</b>			
TRA_REG	On-site training 1 day (regional)	0	1	1
TRA_ADD	Additional on-site training day	0	1	1
TRA_YOUI	1 day training valid for one participant	4	0	0
<b>SOFTWARE &amp; TOOLKIT</b>	<b>DESCRIPTION</b>			
SOUNDVISION	3D simulation software free of charge	1	1	1
SOUNDVISION	3D simulation software available at <a href="http://www.l-acoustics.com">www.l-acoustics.com</a>	1	1	1
TECH TOOLCASE	System technician tool case	1	1	1
<b>SERVICE STARTER KIT KUDO</b>	<b>DESCRIPTION</b>			
KR HSBM11	Kit diaphragm for 1.75" driver	2	2	4
KR HPBM11	Kit HP BM11 Driver 1.75" - 16 ohms	1	1	2
KR HPBE51	Kit HP BE51 Speaker 5"	4	4	4
KR HPBC122	Kit HP BC122 Speaker 12"	2	4	4
KR PIN665	Kit 10 pins 9.5mm diameter screws & rivets	2	4	4
KR CAPLATPIN	Kit 10 pins for dolly boards	2	2	2
<b>SERVICE STARTER KIT SB18</b>	<b>DESCRIPTION</b>			
KR HPBC182	Kit HP BC182 Speaker 18" - 8 ohms	2	0	0
KR CAPLATPIN	Kit 10 pins for dolly boards	1	0	0
<b>SERVICE STARTER KIT SB28</b>	<b>DESCRIPTION</b>			
KR HPBM181	Kit HP BM181 Speaker 18"	0	2	2
KR CAPLATPIN	Kit 10 pins for dolly boards	0	1	1




# CONFIGURATION AND KIT LIST: KUDO

## 12 KUDO FOH (2.7 OHMS)



## 18 KUDO FOH (2.7 OHMS)





24 KUDO FOH (4 OHMS)

